

## Safety and Warning Information



Aside from the power supply module, only ***one*** additional module (Ethernet Switch, Ring Switch or Ethernet Switched Media Converter) may be connected to the module's Interconnection Bus.



Connect the DIN Rail via the End Clamp (2A09) to protective earth ground with low impedance. The modules are grounded to PE when they are snapped onto the DIN Rail.



When used in Hazardous Locations:  
Class I, Division 2, Groups A, B, C & D, T4.  
Substitution of components may impair suitability for Class I, Division 2. Power, input and output (I/O) wiring must be in accordance with Class I, Division 2 wiring methods and in accordance with the authority having jurisdiction. Do not connect/disconnect equipment unless area is known to be non-hazardous and power is switched off. Certified components for use in a suitable enclosure. The maximum ambient temperature is 85°C.

## 2C52

EOTec 2000 Ethernet  
Unmanaged Switch  
Expansion Module

### Installation Instructions

*Important Notice* - Before utilizing the product, the user should determine the suitability of the product for its intended use. The user assumes all risk and liability in connection with such use. WEED INSTRUMENT'S WRITTEN WARRANTY FOR THE PRODUCT IS MADE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. The user's exclusive remedy for breach of Weed Instrument's written warranty shall be the repair or replacement of such quantity of product which is proven to be defective. In no case shall Weed Instrument be liable for any special, incidental, or consequential damages based upon breach of contract, negligence, strict liability or other legal theory.



### Weed Instrument Co., Inc. Round Rock, Texas, USA

Further technical information can be obtained by contacting Weed Instrument Co., Inc., Fiber Optic Products Group.

Phone: 800.880.9333  
512.434.2850

Fax: 512.434.2851

Email: [fiberop@weedinstrument.com](mailto:fiberop@weedinstrument.com)

Visit: [www.weedinstrument.com](http://www.weedinstrument.com)

<b>Ethernet Standards:</b>	IEEE 802.3(U)(X)
<b>Ethernet Protocols:</b>	All 802.3 supported
<b>Ports</b>	
<b>RJ45 Ports (4):</b>	10/100Base-T(X)
<b>Bus Port:</b>	100Base-TX
<b>Module Power Input Requirement:</b>	7.5Vdc @ 500mA via the integrated Interconnection Bus

## Operational Settings

Little or no user configuration and no supervisory processors are required, once connections are made, the unit will immediately begin operating. The data rates are automatically negotiated and the ports will auto-sense Full or Half duplex operation. The unit will automatically learn the addresses of the devices connected to each port (up to 1024) and will buffer and route messages accordingly. Each port has 205 buffers of 128 bytes each. Broadcasts/Multicasts will be sent out all but the source port and are limited to 25% of the available bandwidth.

The unit supports flow control frames on both transmit and receive. Illegal frames per IEEE 802.3 will be dropped. Packets experiencing 16 collisions or late collisions (after 512 bit times) will also be dropped.

## DIN Rail Mounting

### Installation on DIN rail:

Place the top lip of the module's DIN rail mounting channel onto the DIN rail. Push the lower portion of the module towards the mounting surface until it "clicks" and locks into place. Firmly slide the modules together such that the module sides are touching. This ensures a good connection of the integrated BUS interconnection at the rear of the modules. Install End Clamps (Model 2A09) to both sides of the module bundle to prevent accidental unplugging of the BUS interconnections. The End Clamps also provide convenient screw terminals for connecting the DIN rail to protective earth ground.

### Removal from DIN rail:

Remove the End Clamps from the module bundle. Disconnect the BUS interconnections by sliding the modules at least 1/2" apart from each other on the DIN rail. Insert a screwdriver into the rectangular hole in the metal mounting latch at the bottom of the module. Pushing up on the screwdriver's handle causes the latch to move downward and disengages it from the DIN rail. Tilt the module up and lift it off of the DIN rail.

## Connections

### Power:

Power to the unit is supplied from the module's integrated Interconnection Bus typically from a compatible EOTec 2000 power supply and/or 2104 Ring Switch module.

### Interconnection Bus Port:

At this port, **one** additional EOTec Ethernet product such as the 2104 Ring Switch can be connected to assist in forming star and/or daisy chain network configurations.

### Ethernet:

The front panel RJ45 connectors are shielded and employs an auto-crossover circuit such that either a straight-through or cross-over cable may be connected. Shielded, data-quality, category 5 cable is recommended. The typical maximum cable length is 328ft(100m).

## LED Indicators

PWR (Power): Green - On with power connected

(RJ45 Ports)

ACT: Green - Off with no connection  
On with proper link  
Flashes with link activity

100: Amber - Off at 10Mbps  
On at 100Mbps

BUS/ACT  
(Bus Port):

Green - Off with no connection  
On with proper link  
Flashes with link activity

## Specifications/Compliances

Ethernet Standards:	IEEE 802.3(U)(X)
Ethernet Protocols:	All standard IEEE 802.3
Ethernet Isolation:	1200VRMS (1 minute)
Ethernet Ports	
4, Shielded RJ45:	10/100 Base-T(X)
1, Interconnect Bus:	100 Base-TX
Ethernet Cable Length:	328ft (100m) max typical
Power Requirements:	Via Interconnection Bus from adjacent power supply or 2104 module, 7.5Vdc at 500mA
Weight:	< 6.5oz (185g)
Operating Range	
Temperature:	-40 to 85°C
Relative Humidity:	5 to 95% (non-condensing)
Flammability:	UL 94V-0
Hazardous Locations:	Class I, Division 2, Groups A, B, C & D, T4